

CEILING SPEAKER 30W 2 CLOSE VOICES LTS.PL2030C

Operation manual








TABLE OF CONTENTS


1. Di	mensions	Page :	3
2. Ins	stallation	.Page (3
3. Sp	pecifications	Page (3
4 Inc	structions	Page 4	1



1. DIMENSIONS



2. INSTALLATION



Step 1

With a measurement tool measuring speaker hole in the ceiling opening size, the wiring through the hole to open a good connection on the speaker.

Step 2

Separate speakers on both sides of the iron, so that the edge close to the ceiling speakers, the merger places in the ceiling hole.

Step 3

So that speakers and fixed on the ceiling, and the completion of the installation of speakers.

3. SPECIFICATIONS

Frequency response	100Hz – 20 kHZ
Power taps 100V	0.75W / 1.5W / 3W / 6W
SPL max.	102 dB @ 100V 15W
Sensitivity	89 dB (+/- 3 dB)
Power supply	30W
Materials	ABS
Color	White RAL 9016
Dimensions housing	Diameter 210 mm
Dimensions	240 x 155 mm
Weight	2.10 kg



4. INSTRUCTIONS

We would like to note that all products have been tested and the commitment to keep our quality. Loudspeaker broadcast pan-for hotels, commercial buildings, supermarkets, schools, leisure and entertainment venues, is your ideal choice. For your installation, commissioning and use of this product, the installation please read this note.

Safety tips

- Please be sure to use the former reading detailed notes.
- Really pay attention to this manual and a safety with the important warning.
- Recommend that you keep this manual for future reference.

Common warning signs and security

The manual shown warning signs and security is to prevent the improper operation due to personal injury arising from the loss of property. Please read before using this product must understand that this manual security symbols and warning to indicate fully aware of potential risks.



Warning

Such as the inappropriate use of staff will cause injury, death and property damage.

When installed loudspeakers

- Definitely will not be allowed to speakers and any exposure in the rain-wet or water, may be inconsistent with fire.
- Restricted by the provisions of the speakers on the voltage, such as the use of high voltage may cause electric shock or fire disaster. Is no pruning, distorted or replacement of damaged wires.
- Avoid instability in the installation or set up speakers, such as shaking the table or flat surface, the speaker can avoid falling caused personal injury or property damage.
- Speakers will be installed in support of the speaker or the weight of a solid shelf. Speaker swap can be avoided caused personal injury or property damage.
- Wet hands must not be admitted into or plugs, may lead to electric shocks.
- The allocation of plugs, make sure that pull plugs, rather than pull wires. The use of a damaged power line of machinery may cause fire or electric shock.
- Mobile speaker, you plug the prior allocated. If the speaker and plugs may be moving together will cause fire or electric shock. For plugs, identified as plugs for grip.
- Will not be allowed to speakers on the vent cover. May cause internal heating caused by the fire.
- Avoid speakers installed in the humidity or dust, direct contact with the sun, from the near-electric, smoke or steam, may cause fire or electric shock.

LINEARSOUND

